



UPRIGHT ASSEMBLY

For Streeter Super Stands Sprint and Kid Kart Uprights



SPRINT model Upright shown



Included Hardware:

- Casters (4)
- Adjusting Knobs (2)
- Frame Mounting Bolts and Nuts (3 each)
- Carrage Bolts and Nuts (2 each)
- Caster Mounting Bolts, Nuts and Washers (16 each)



Install Upright frame onto base. Tighten bolts (three per side) using 1/2" wrench/ socket.



Carrage bolts install through each of the threaded tabs. You may need a 3/8" wrench to help install the carrage bolt through the tab. Thread on Nut and Tightening Knob. Tighten the nut to the knob using a 1/2" wrench.



Install casters and tighten bolts/nuts. (1/2" wrench)

If you require additional/replacement hardware or tech assistance contact us at: (262) 457-5018



streetersuperstands.com